



SOR SummerTop® Footman Loop Installation Instructions

Specter Off-Road, Inc. • 21600 Nordhoff Street • Chatsworth • California 91311 • USA
(818) 882-1238 • Fax: (818) 882-7144 • E-Mail: sor@sor.com • www.sor.com

These instructions cover SOR SummerTop® model numbers: #272-20, #272-23, #272-30 & #272-35.

Install one footman loop on each top corner of the rear quarter panel of the vehicle. Set the footman loop in place and mark the location of holes. Center punch and drill two 5/32" holes for each footman loop. Secure each footman loop in place with two #8 x 1/2" Phillips head screws.

1. Slide in plastic strip into windshield channel mounted to top of windshield frame.
2. Pull back material over roll bar.
3. Pull rear strap thru footman loops, pull strap thru the buckle and tighten.

