



21600 NORDHOFF ST.
CHATSWORTH, CALIFORNIA 91311 USA
PH: (818) 882-1238
E-Mail: sor@sor.com
Internet: <http://www.sor.com>

#239-60 TAIL LIGHT GUARDS FITS 60 & 62 SERIES INSTALLATION INSTRUCTIONS

STEP 1. First separate the right side from the left side tail guard. Open tailgate. Align guards square on vehicle. Align the bars so the separation of the colored lens are covered by the bars.

STEP 2. Using a scribe, mark the mount holes. Center punch hole to be drilled on the body. Use a 1/8" drill bit. Drill holes in body.

STEP 3. Hold guard on body in position with drilled holes. Clean body area with a cleaner in the area where the hook & loop tape will be attached to body. Attach hook & loop tape to guard with position to tape on body.

STEP 4. Install guard for the final time. Install self tapping screws & tighten.

