



21600 NORDHOFF ST.
CHATSWORTH, CALIFORNIA 91311 USA
PH: (818) 882-1238 FAX: (818) 882-7144
E-Mail: sor@sor.com
Internet: <http://www.sor.com>

#244-82 SOR PADDING KIT INSTALLATION INSTRUCTIONS

PLEASE READ INSTRUCTIONS BEFORE INSTALLATION

Check all contents of your kit before you begin to install. Your kit should contain three lengths of roll bar padding, and three roll bar pad covers.

Tools you will need for this installation: pen or pencil, masking tape, tape measure, scissors, glue.

1. Using your tape measure, locate the center point of the top of the main hoop of the sports bar.
2. Starting with your first length of foam, cut a slit down the side of the padding end to end. Next take this piece of foam and starting at the top of the main hoop at the center point, install the foam around the tube.
3. Carefully stretch the foam around the tube so both edges meet, use a short piece of masking tape to hold the edges together. Continue to stretch the foam and secure it with the masking tape down the entire length of the foam, approximately every three inches. Carefully fit the foam around the radius of the curve of the roll bar. The smoother you make the padding fit the bar, the better your padding cover will fit over the foam. See picture A.
4. At the base of the curve, where the rear support bar meets the main hoop, carefully trim the foam padding to fit the intersection between the two bars. The padding should fit snug around the intersection. Continue to tape the padding around the bar to the end. Using the next length of foam, continue in the same manner around the other half of the main hoop.
5. Take your next length of foam, slit lengthwise, end to end as you did before, then cut the foam into two equal pieces. These pieces will install on the rear support bars. Secure the foam to the support bars as you did for the main hoop. Again, the smoother you make the padding around the curves the better the padding covers will fit.
6. Take the main hoop cover, locate the seam at the center of the cover, wrap the cover around the bar with the velcro type fasteners. Position the main hoop cover so that the center seam is even with the center location marked on the main hoop and the Specter label is facing toward the front of the vehicle. Carefully wrap the cover around the main hoop aligning the center seams and working your way outwards toward the ends. Continue to install the cover till you meet the rear side support bars.
7. This cover has marks where the side support bar hole should be cut. Verify that your side support bars are in the same location of the marked cut outs. Your cut outs may be in slightly different locations. Check the position of both holes on the cover prior to cutting them out. Next you will need to seal the threads attaching the velcro to the cover prior to cutting, so the threads will not unravel. Using glue, fingernail polish or modeling cement, dab on the threads surface to seal and secure the threads. When cutting the holes, start by cutting across the velcro into the center of the hole. The hole should be no more than two inches in diameter and snug fit around the rear support bar. Finish attaching the pad cover on to the remainder of the hoop. See picture B.
8. To install the rear side support bar covers, position the cover seam at the top of the bar so that the Specter label is facing toward the outside of the vehicle. Using the same procedure install the cover working your way toward the ends, keeping a smooth finish around the curves.



21600 NORDHOFF ST.
CHATSWORTH, CALIFORNIA 91311 USA
PH: (818) 882-1238 FAX: (818) 882-7144
E-Mail: sor@sor.com
Internet: <http://www.sor.com>

#244-82 SOR PADDING KIT INSTALLATION INSTRUCTIONS

Photo A



Photo B

