



21600 NORDHOFF ST.
CHATSWORTH, CALIFORNIA 91311 USA
PH: (818) 882-1238 FAX: (818) 882-7144
E-Mail: sor@sor.com
Internet: <http://www.sor.com>

#272-35 FAMILY SUMMER TOP

Install one footman loop on each top, rear quarter panel of the vehicle. Set the footman loop in place and mark the location of holes. Center punch and drill 2 5/32" holes for each footman loop. Secure each footman loop in place with two #8 x 1/2" phillips head screws.

1. Slide in plastic strip into windshield channel mounted to top of windshield frame.
2. Pull back material over roll bar.
3. Pull rear strap thru footman loops , pull strap thru buckle and tighten.

