



21600 NORDHOFF ST.
CHATSWORTH, CALIFORNIA 91311 USA
PH: (818) 882-1238 FAX: (818) 882-7144
E-Mail: sor@sor.com
Internet: http://www.sor.com

#284-30 ProComp Steering Stabilizer

Installation Instructions

Please read all instruction from start to finish before you begin installation

1. Turn the steering wheel so the tires are in the straight position.
2. Install bracket A on the axle using the U-bolts and nuts provided. **NOTE: Depending on your vehicle, you may install the bracket in either position as per the illustrations below.**
3. Install the large diameter end onto the bracket A as per the illustration.
4. Install bracket B onto the cylinder rod stud as per illustration.
5. Pull the cylinder rod out half of its travel length and attach bracket B to the tie rod using the U-bolts supplied with your kit. **NOTE: Cylinder rod end should be slightly higher than the cylinder end.**
6. Turn the steering wheel fully right and fully left being sure there is not interference or binding
7. double check all nuts and bolts for tightness periodically
8. Omit bracket A on Toyota 4X4 Pick-ups. Use the stock axle mount.

