



21600 Nordhoff Street, Chatsworth, CA 91311  
PH: (818) 882-1238 FAX: (818) 882-7144  
E-Mail: sor@sor.com Internet: <http://www.sor.com>

---

## #310-45RE FRONT UPHOLSTERY SEAT COVER FITS 1/79-1984 FJ45/HJ/47 RIGHT HAND DRIVE

### **PROFESSIONAL INSTALLATION RECOMMENDED**

#### **PLEASE READ INSTRUCTIONS BEFORE INSTALLATION**

The fit of your new seat covers will depend on the condition of your foam. Replacement foam is available see page 308 in Specter Off-Road catalog. To insure proper fit and ease of installation, the seat covers should be installed in no less than 75 degrees Fahrenheit. It's recommended to put them in the sun to warm up, or under a lamp to make the material more flexible and easier to handle. The end result will be a nice tight fit.

Seat covers set includes 2 back bucket seat covers, 2 bottom bucket seat covers, wires and bag of hog rings.

**TOOLS REQUIRED:** Hog ring pliers, metric sockets, and scissors.

#### **INSTALLATION INSTRUCTIONS**

1. Remove the seats from the vehicle for installation of seat covers. Match wires with the corresponding vinyl loop sizes.

#### **Bottom Seat Cover Installation**

1. Remove the old seat covers.
2. Fold the front and back flap upward and insert wires into the flap on the underside of cover.
3. Center the cover over the foam. Position the flap and wire into the cutout in the cushion and attach to frame with hog rings.
4. Fold the front and rear flaps around the cushion, pulling the cover tight.
5. Insert wires into the back flap.
6. Pull the wire around the bottom edge of the cover tight and attach with hogrings to the desinated locations on the frame.
7. Pull the back flap tight and attach to the frame with hog rings.

#### **Backrest installation**

1. Remove the old seat covers. Headrest guides must be removed from inside, underneath old upholstery.
2. Turn the cover inside out, center and position the cover over the top and corners of the backrest.
3. Reinstall retaining wire in the loop on the backside of the cover. Note Specter Off-Road sew bar label should now be at the top of the cover facing you and the flap is below.
4. Position the flap and wire into the cutout then attach to the frame with hog rings.
5. Continue pushing the cover down to the flap on the front. Make sure the top and corners are properly aligned.
6. Reinstall wire into the flap, position the flap and wire into the cutout and attach to the frame with hog rings.
7. Push the cover completely down over the backrest. 8. Turn the backrest upside down and pull the cover tight.
9. Reinstall wire into the back of the cover and into the front of the cover.
10. Pull the cover snug and attach the two wires in step 9 with hog rings.
11. Attach the backrest to the cushion. Reinstall the finished seats into the vehicle.

**Specter Off Road Inc. is not liable for damage or replacement due to improper installation.**