



21600 NORDHOFF ST.
CHATSWORTH, CALIFORNIA 91311 USA
PH: (818) 882-1238 FAX: (818) 882-7144
E-Mail: sor@sor.com
Internet: <http://www.sor.com>

#321-40 40 SERIES SLIDERS INSTALLATION INSTRUCTIONS

1. Remove existing window glass and weatherstrip.
2. Note boxes are marked RH & LH.
3. Remove retaining ring from main frame of slider. On the inside edge of the main frame is foam back tape for sealing frame to body.
4. Insert slider body into body opening making sure that the sliding part is to the rear of the vehicle and the drain holes are at the bottom of the opening. Center slider in the body opening.
5. Take ring, screws, phillips screwdriver, and screw ring inside vehicle. Start installing screws at center of the verticals working your way around to the horizontals. Make sure all screws are tight and the job is done.

Now enjoy your Specter custom 40 Series Sliders!