



21600 NORDHOFF ST.  
CHATSWORTH, CALIFORNIA 91311 USA  
PH: (818) 882-1238 FAX: (818) 882-7144  
E-Mail: [sor@sor.com](mailto:sor@sor.com)  
Internet: <http://www.sor.com>

---

#343-600, #343-662 & #343-800

60, 62 & 80 SERIES MOLDED CARPET SETS

## INSTALLATION INSTRUCTIONS

1. Remove front and rear seats, center console, side plates and kickplates.
2. If underfelt is O.K. leave in, otherwise replace.
3. Old carpet (if not badly worn) can be used as a template to cut all holes.
4. Start with rear carpet - place "flaps" under backseat.
5. Push carpet firmly into corners of floor - cut slots for handbrake, seatbelts, and small holes for seats.
6. Place front carpet into position and push firmly up over transmission tunnel.
7. Replace seats.
8. Trim sides of carpet under doors - leave enough carpet to fit under side plates.