



21600 NORDHOFF ST.
CHATSWORTH, CALIFORNIA 91311 USA
PH: (818) 882-1238 FAX: (818) 882-7144
E-Mail: sor@sor.com
Internet: http://www.sor.com

#309-833-TP PASSENGER TUFF DUCK SLIP COVER FITS 1/98 - 2007 100 SERIES

PLEASE READ INSTRUCTIONS BEFORE INSTALLATION

Warm up slip covers in the sun till they are soft and warm before installation. Or you can put slip cover inside pillow case and put in clothes dryer for a few minutes. Be careful to close slip cover so the slip covers do not come in contact with the dryer drum, other wise you will melt the backing on this slip cover.

Be sure to hook the loop strips sewn on the underside of the headrest covers, along the back and sides of the cushions are separated. When properly installed, the tags on the back seat pockets should be facing each other.

INSTALLATION INSTRUCTIONS

Large Backrest

- STEP 1. With the backrest in the upright position, remove the headrests. Position the slip cover over the backrest, be sure to insert the release lever in the cutout of the slip cover as you pull them down.
- STEP 2. Open up the hook & loop front closure, pull out the seat belt so it is on the outside of the slip cover, then mate the hook & loop back to the closed position for a nice finished look. Push the center flap thru to the backside of the seat.
- STEP 3. Tilt the seat backrest forward, mate the hook strip on the flap at the bottom of the slip cover to mate with the loop strip on the underside of the bottom of the backrest.
- STEP 4. Mate the hook and loop strip at the front side flaps.

Large Cushion

- STEP 1. With the backrest in the upright position, install the bottom slip cover over the bottom cushion. Separate the hook and loop closure in the center so the seat belt can fit in the center seat belt cutout, then mate the hook & loop back in the closed position. Push the center flap thru to the back side of the seat. Now fold the backrest forward just enough to be able to reach the center flap and pull it thru to the back side. Now you are ready to wrap around the side flaps and mate the hook and loop closure to the center flap for a nice tight fit.

Small Backrest

- STEP 1. With the seat in the upright position, remove the headrest. Position the cover over the backrest, be sure to insert the release lever in the cutout of the slip cover as you pull them down. Push the center flap thru to the backside of the seat.
- STEP 2. Tilt the seat backrest forward, mate the hook strip on the flap at the bottom of the slip cover to mate with the loop strip on the underside of the bottom of the backrest.
- STEP 3. Mate the hook and loop strip at the front side flaps.

Small Cushion

- STEP 1. Position the cover over the cushion and the flap into the opening between the cushion and backrest.
- STEP 2. Fold the seat forward and mate the hook strip on each side with the loop strip on the flap. Be sure the latch release is in the cutout.

Headrests

Reinstall each headrest and secure in the upper, first latch position. Fit a cover over each headrest. Mate the hook and loop strips on the underside.

CARE INSTRUCTIONS

Cold water wash, line dry. May be dry cleaned, no Trichlorethylene.

NOTE: if covers are left in direct sunlight for extended periods of time the covers will tend to fade.