



21600 NORDHOFF ST.  
CHATSWORTH, CALIFORNIA 91311 USA  
PH: (818) 882-1238 FAX: (818) 882-7144  
E-Mail: sor@sor.com  
Internet: http://www.sor.com

---

## #308-225-VGYR REAR UPHOLSTERY SEAT COVER FITS 8/80-1/90 FJ60 & FJ62

### PROFESSIONAL INSTALLATION RECOMMENDED

#### PLEASE READ INSTRUCTIONS BEFORE INSTALLATION

The fit of your new seat covers will depend on the condition of your foam. Replacement foam is available see page 308 in Specter Off-Road catalog. To insure proper fit and ease of installation, the seat covers should be installed in no less than 75 degrees Fahrenheit. It's recommended to put them in the sun to warm up, or under a lamp to make the material more flexible and easier to handle. The end result will be a nice tight fit.

Seat covers set includes 1 back bench seat cover, 1 bottom bench seat cover, and bag of hog rings.

TOOLS REQUIRED: Hog ring pliers, Phillips head screwdriver, metric sockets, scissors and a tool to make small holes such as a sharp punch or awl. Please note this punch or awl will be used to locate the small holes that attach the frames to the backrest and cushion. The tool MUST NOT be larger than the holes for the small Phillips head screws.

#### INSTALLATION INSTRUCTIONS

1. Remove the backrest and the cushion from the vehicle. Unbolt the cushion from the floorboard.

#### Backrest Seat Cover Installation

1. Remove the old seat covers. Headrest guides must be removed from inside, underneath old upholstery. Reuse retaining wires, and headrest guides.
2. Insert retaining wire into each flap on the underside. Center and positioning each flap and wire to the corresponding cutout in the backrest and attach to the frame with hog rings.
3. Position the cover around the top, sides and bottom.
4. Insert long wire into the bottom of the cover.
5. Pull the retaining wire in the seat cover, attach hog rings at each location in the back to hold the cover on tightly.
6. Align the side latch mechanism and CAREFULLY cut out the area for the screw holes. Reinstall each side latch mechanism.
7. Install the frame, using the sharp punch or other tool that you selected to locate the holes for the screws.
8. When installing the frame, make sure all retaining wires and hog rings are under the frame.
9. Reinstall the backrest into the vehicle.

#### Bottom Seat Cover Installation

1. Remove the old seat covers, retain all hardware and retaining wires.
2. Fold the front and sides of the seat cover upward, insert the retaining wires into the flap on the underside.
3. Center and position each flap and wire into the corresponding cutout in the cushion and attach to the frame with hog rings.
4. Fold the front and sides around the cushion.
5. Pull the retaining wires in the seat cover tightly and attach with hog rings on the underside.
6. Reinstall the frame, using the sharp punch or other tool that you selected to locate the holes for the screw.
7. When installing the frame, make sure all retaining wires and hog rings are under the frame.
8. Carefully cutout the areas for the latch release mechanism and screw holes. Reinstall the latch mechanism.
9. Install the cushion in the vehicle.

#### Care instructions

Cold water wash, line dry. May be dry cleaned, no trichlorethylene.

NOTE: if covers are left in direct sunlight for extended periods of time covers will tend to fade.

Specter Off Road Inc. is not liable for damage or replacement due to improper installation.